



BI-METALLIC THERMOMETERS: INSTALLATION & OPERATION MANUAL



SAFETY WARNING

**INCORRECT USE OF BI-METALLIC
THERMOMETERS CAN CAUSE
DAMAGE & INJURY**

1. BEFORE INSTALLING POCKET, CAREFULLY REMOVE THERMOMETER FROM POCKET BY LOOSENING M4 SIDE SCREW.
2. INSTALL POCKET USING AN APPROPRIATE SEALING METHOD AND CHECK FOR LEAKS.
3. INSERT THERMOMETER BACK INTO POCKET.
4. ROTATE THERMOMETER INTO A POSITION SUITABLE FOR READING.
5. TIGHTEN SIDE SCREW.

NOTE: THE STEM OF A BI-METALLIC THERMOMETER IS NOT SEALED. THEREFORE, IT MUST NOT BE USED TO MEASURE THE TEMPERATURE OF A LIQUID WITHOUT A POCKET.